


# 零件表PARTS LIST    WH-2513B

| 圖號<br>NO. | 編號CODE        | 名稱      | DESCRIPTION               | Q'TY | 圖號<br>NO. | 編號CODE        | 名稱        | DESCRIPTION                     | Q'TY |
|-----------|---------------|---------|---------------------------|------|-----------|---------------|-----------|---------------------------------|------|
| 01        | B010110331    | 曲軸箱     | Crankcase                 | 1    | 12-4      | BS14108016100 | 圓頭螺絲      | Screw                           | 5    |
| 01-1      | B180610050    | 型式規格黏標  | Model Sticker             | 1    |           | BS32108200    | 彈簧華司      | Spring Washer                   | 5    |
| 01-2      | B180101000    | 流水號數黏標  | MFG. No. Sticker          | 1    | 13        | B011810000    | 排油螺絲      | Drainage Screw                  | 1    |
| 02        | B010210000    | 柱塞油封    | Piston Oil Seal           | 3    | 13-1      | BG1010601770  | O形環       | O-Ring                          | 1    |
| 03        | B010307000    | 腳座      | Crankcase Stand           | 2    | 14A       | B011910001    | 加油蓋組      | Oil Inlet Cover Assy.           | 1    |
| 03-1      | BS11112016122 | 六角螺絲附華司 | Set Bolt, Washer          | 4    | 14        | B011910000    | 加油蓋       | Oil Inlet Cover                 | 1    |
| 04AN      | B013010015    | 柱塞組     | Piston Assy.              | 3    | 14-1      | BG1024002900  | O形環       | O-Ring                          | 1    |
| 04-1N     | B013110020    | 柱塞桿     | Piston Rod                | 3    | 21        | B020110110    | 汽缸        | Cylinder                        | 1    |
| 04-2N     | B013210001    | 柱塞套     | Piston Sleeve             | 3    | 21-1      | BS16110064500 | 內六角螺絲     | Set Bolt                        | 8    |
| 04-3N     | B013410020    | 柱塞套固定螺帽 | Nut                       | 3    | 21-2      | BS33110400    | 安全華司      | Safety Washer                   | 8    |
| 04-4      | BG1005000906  | O形環     | O-Ring                    | 6    | 22        | B020310080    | U形防水圈     | U-Ring                          | 3    |
| 04-5N     | BG3005300820  | 背托環     | Back-Up Ring              | 3    | 23        | B020310090    | U迫緊墊片     | Spacer                          | 3    |
| 04-6      | B013510000    | 柱塞套平墊圈  | Washer                    | 3    | 24        | B021210020    | 迫緊中間環     | Spacer Ring                     | 3    |
| 04-7      | B013310020    | 柱塞套固定螺絲 | Set Bolt                  | 3    | 25        | B020310040    | U形迫緊      | U-Packing                       | 3    |
| 05        | B010510010    | 柱塞銷     | Piston Pin                | 3    | 26        | B021110000    | 迫緊上環      | Packing Upper Ring              | 3    |
| 06        | B010610001    | 連桿      | Connecting Rod Assy.      | 3    | 26-1      | BG1030003503  | O形環       | O-Ring                          | 3    |
| 07        | B010710010    | 軸承      | Bearing                   | 2    | 27        | BS5001600     | 塞頭 PT 1/2 | Plug PT 1/2                     | 1    |
| 08        | B010810550    | 曲軸      | Crankshaft                | 1    | 28        | BS5001200     | 塞頭 PT 3/8 | Plug PT 3/8                     | 1    |
| 08-1      | B012109000    | 曲軸鍵     | Crankshaft Key            | 1    | 29        | BS5000400     | 塞頭 PT 1/8 | Plug PT 1/8                     | 1    |
| 09        | B010910040    | 曲軸油封    | Crankshaft Oil Seal       | 2    | 30A       | B040010011    | 活門組       | Valve Assy. (WH-2112M,WH-2012E) | 6    |
| 10        | B011010000    | 曲軸油封蓋   | Crankshaft Oil Seal Cover | 2    | 30A       | B040011031    | 活門組       | Valve Assy. (WH-2512M)          | 6    |
| 10-1      | BS12108010100 | 大扁頭螺絲   | Screw                     | 8    | 30-2      | B040109000    | 活門塞       | Valve Plug                      | 6    |
| 12        | B011610331    | 曲軸箱後蓋   | Rear Cover                | 1    | 30-4      | B040210000    | 活門座       | Valve Seat (WH-2112M,WH-2012E)  | 6    |
| 12A       | B012201003    | 油鏡組     | Oil Window Assy.          | 1    | 30-4      | B040211000    | 活門座       | Valve Seat (WH-2512M)           | 6    |
| 12-1      | B012201020    | 油鏡      | Oil Window                | 1    | 30-5      | B040310010    | 活門帽       | Valve Cage                      | 6    |
| 12-2      | BG1023402870  | O形環     | O-Ring                    | 1    | 30-6      | BJ20901000    | 活門彈簧      | Valve Spring                    | 6    |
| 12-3      | B011710000    | 後蓋迫緊    | Rear Cover Packing        | 1    | 30-7      | BG1016002102  | O形環       | O-Ring                          | 6    |


# 零件表PARTS LIST      WH-2513B

| 圖號<br>NO. | 編號CODE        | 名稱         | DESCRIPTION                       | Q'TY | 圖號<br>NO. | 編號CODE        | 名稱          | DESCRIPTION                   | Q'TY |
|-----------|---------------|------------|-----------------------------------|------|-----------|---------------|-------------|-------------------------------|------|
| 30-8      | BJ21001210    | 活門輔助彈簧     | Spring                            | 5    | 68        | B070509000    | 壓力閥桿        | Valve Rod                     | 1    |
| 41        | B021310050    | 活門固定螺絲(無孔) | Set Bolt W/O Hole                 | 5    | 69        | B070909000    | 消音片         | Damper Plate                  | 1    |
| 41-1      | B021410050    | 活門固定螺絲(有孔) | Set Bolt W/Hole                   | 1    | 70        | B070309000    | 陶瓷球閥        | Ceramic Ball Valve            | 1    |
| 41-2      | BG1020002502  | O形環        | O-Ring                            | 6    | 71A       | B070409001    | 壓力閥座組       | Valve Seat Assy.              | 1    |
| 42        | B021701000    | 進水接頭       | Inlet Connector                   | 1    | 71        | B070409000    | 壓力閥座        | Valve Seat                    | 1    |
| 43        | BK20201040    | 快速接頭       | Quick Connector                   | 1    | 71-1      | BG3018302231  | 背托環         | Back-Up Ring                  | 1    |
| 44        | B022310000    | 潤滑水管       | Lubricating Pipe                  | 1    | 71-2      | BG1017002202  | O形環         | O-Ring                        | 1    |
| 44-1      | BG1011001502  | O形環        | O-Ring                            | 1    | 71-3      | BG1020002502  | O形環         | O-Ring                        | 1    |
| 45        | B022410000    | 潤滑水管螺絲     | Screw                             | 1    | 72C       | B070211050    | 迴水座         | Overflow Chamber              | 1    |
| 45-1      | BG1013001602  | O形環        | O-Ring                            | 1    | 72-1      | BG1011001502  | O形環         | O-Ring                        | 2    |
| 45-2      | BG1011001502  | O形環        | O-Ring                            | 1    | 72-2      | BS16108025500 | 內六角螺絲       | Screw                         | 4    |
| 51        | B031110000    | 壓力錶        | Pressure Gauge                    | 1    | 72-3      | BS33108400    | 安全華司        | Safety Washer                 | 4    |
| 52        | B031210000    | 壓力錶接頭(單機)  | Pressure Gauge Coupling (Pump)    | 1    | 73        | B071409000    | 彈簧下座(單機)    | Spring Seat (Pump)            | 1    |
|           | B031210010    | 壓力錶接頭(整組)  | Pressure Gauge Coupling (Cleaner) |      | 73B       | B071411000    | 彈簧下座(整組)    | Spring Seat (Cleaner)         | 1    |
| 60A       | B070011011    | 自動洩壓總成(單機) | Unloading Valve Assy. (Pump)      | 1    | 73-1      | B071311000    | 彈簧上座        | Spring Seat (Upper)           | 1    |
| 60B       | B070011001    | 自動洩壓總成(整組) | Unloading Valve Assy. (Cleaner)   |      | 73B-1     | B071510000    | 調壓橫棒(整組)    | Adjusting Pin (Cleaner)       | 1    |
| 61        | B070111050    | 洩壓汽缸套      | Unloading Valve Cylinder          | 1    | 73B-2     | B071610000    | 調壓橫棒加強套(整組) | Adjusting Rod Cover (Cleaner) | 1    |
| 62        | BJ50901000    | 洩壓輔助彈簧     | Auxiliary Spring                  | 1    | 74        | BJ41101000    | 調壓彈簧        | Pressure Regulating Spring    | 1    |
| 63A       | B070609001    | 柱塞活門組      | Piston Valve Assy.                | 1    | 75        | B071709000    | 調壓螺帽(單機)    | Regulating Nut (Pump)         | 1    |
| 63        | B070609000    | 柱塞活門體      | Piston Valve Body                 | 1    | 75A       | B071711000    | 調壓螺帽(整組)    | Regulating Nut (Cleaner)      | 1    |
| 63-1      | BG1015002002  | O形環        | O-Ring                            | 2    | 77        | B053301010    | 固定螺帽        | Set Nut                       | 1    |
| 63-2      | BG3016202000  | 背托環        | Back-Up Ring                      | 3    | 77-1      | BG1016002102  | O形環         | O-Ring                        | 1    |
| 64        | B070709000    | 止水閥塞       | Valve Seat                        | 1    | 79        | BS11108051300 | 六角螺絲        | Set Bolt                      | 1    |
| 65        | BJ30901000    | 球閥固定彈簧     | Spring                            | 1    | 79-1      | BS21108200    | 六角螺帽        | Nut                           | 2    |
| 66        | B070809000    | 球閥固定套      | Ball Valve Seat                   | 1    |           |               |             |                               |      |
| 67        | B071109050    | 固定環        | Set Ring                          | 1    |           |               |             |                               |      |
| 67-1      | BS17106005500 | 無頭內六角螺絲    | Screw                             | 2    |           |               |             | 2013.08 V.                    |      |



WH-2513B

60A



60B

