

PARTS LIST WL-51 / WL-160 SERIES

No.	Code		品名	Description	PCS	No.	Code		品名	Description	PCS
	51	160					51	160			
01	B010103400	B010104000	曲軸箱 (紅)	Crankcase (Red)	1	21	B013303000	B013304000	柱塞套固定螺絲	Double-End Screw	3
	B010103410	B010104310	曲軸箱 (藍)	Crankcase (Blue)	1	22	BG1018002400	BG1023703070	O形環	O-Ring	3
02	B011403000	B011404000	防塵蓋	Dustproof Cover (Blue)	1	23	B013503000	B013504000	柱塞套平墊圈	Gasket	3
03	BP118222430	BP120223602	皮帶輪	Pulley	1	24	B013403000	B013404010	柱塞套固定螺帽	Set Nut	3
04	BS11112032121	BS11112032121	六角螺絲	Set Bolt	1	24-1	BG3019002400	BG3024103000	背托環	Back-Up Ring	3
05	BS12108010100	BS11110013100	大扁頭螺絲	Set Bolt	8	25	B010503110	B010504110	柱塞銷	Piston Pin	3
	N/A	BS32110200	彈簧華司	Spring Washer	8	26	B010403010	B010404010	柱塞	Piston	3
06	B011003110	B011004110	曲軸油封蓋 (A)	Crankshaft Oil Seal Cover (A)	2	27	B010303000	B010304000	腳座	Crankcase Stand	2
06-1	B011102110	B011104000	曲軸油封蓋 (B)	Crankshaft Oil Seal Cover (B)	1	28	BS11112016122	BS11116025200	六角螺絲附華司	Set Bolt,Washer	4
6-2	BG1028003000	N/A	O形環	O-Ring	1		N/A	BS32116200	彈簧華司	Washer	4
07A	B011901111	B011901011	加油蓋組	Oil Inlet Cover Assy.	1	29	B012903000	B012903000	汽缸銷	Set Pin	2
07	B011901010	B011901010	加油蓋	Oil Inlet Cover	1	30	B010203000	B010204000	柱塞油封	Piston Oil Seal	3
07-1	BG1020302550	BG1020302550	O形環	O-Ring	1	31	B011203010	B011204010	柱塞中間皮	Waterproof Ring	3
08	B011703000	B011704000	後蓋迫緊	Rear Cover Packing	1	40	B020103000	B020104000	汽缸	Cylinder	1
09	B011603000	B011604000	曲軸箱後蓋 (紅)	Rear Cover (Red)	1	41	BS11112032122	BS11116042100	六角螺絲附華司	Set Bolt,Washer	4
	B011603310	B011604310	曲軸箱後蓋 (藍)	Rear Cover (Blue)	1		N/A	BS32116200	彈簧華司	Spring Washer	4
10	BS12108016100	BS12108016100	大扁頭螺絲	Set Bolt	5	42	BS15116078100	BS15120100100	雙頭牙螺絲	Double-End Screw	2
11A	B012201002	B012201002	油鏡組	Oil Window Assy.	1	43	BS21116200	BS21120200	六角螺帽	Nut	2
11	B012201010	B012201010	油鏡	Oil Window	1		BS32116200	BS32120200	彈簧華司	Spring Washer	2
11-1	BG1023402870	BG1023402870	O形環	O-Ring	1	44	B020803011	B020804011	黃油杯	Grease Cup	3
12A	B011801001	B011801001	排油螺絲組	Drainage Screw Assy	1	45	B020203000	B020204000	V迫緊底座	V-Packing Seat	3
12	B011801000	B011801000	排油螺絲	Drainage Screw	1	46	B020303030	B020304020	V迫緊	V-Packing (F.P.M)	3
12-1	BG1011001500	BG1011001500	O形環	O-Ring	1		B020303010	B020304010	V迫緊	V-Packing (A120)	3
13	B012101110	B012104000	曲軸鍵	Crankshaft Key	1		B020303020	B020304000	V迫緊	V-Packing (UPE)	3
14	1010803121	1010804120	曲軸	Crankshaft	1		B020303000	B020304050	V迫緊	V-Packing (NBR)	3
15	B010603001	B010604001	連桿	Connecting Rod Assy	3	47	B020403000	B020404000	黃油環	Grease Ring	3
16	B010703010	B010704010	軸承	Bearing	2	48	B020903000	B020904000	V型油環	V-Type O-Ring	3
17	B010903000	B010904000	曲軸油封	Crankshaft Oil Seal	2	49	B020503000	B020504000	調整環	Adjusting Ring	3
18	B013003001	B013004001	柱塞組	Piston Assy	1	49-1	B02430300	B02430300	止滑片	Plater	6
19	B013103000	B013104000	柱塞桿	Piston Rod	3	50	B020703010	B020704010	調整環固定夾	Set Clip	3
20	B013203000	B013204000	柱塞套	Ceramic Piston Sleeve	3	51	B031403000	B031404000	進水室	Suction Chamber	1

No.	Code		品名	Description	PCS	No.	Code		品名	Description	PCS
	51	160					51	160			
51	B031403310	B031404310	進水室	Suction Chamber	1	102	B051603000	B051603000	壓力閥套	Pressure Valve Sleeve	1
52	BS11116051100	BS21120200	六角螺帽	Nut	2	103	B050803110	B050803110	壓力閥桿	Valve Rod	1
	N/A	BS15120070100	雙頭牙螺絲	Double-End Screw	2	103-1	BG1011001501	BG1011001501	O形環	O-Ring	3
	BS32116200	BS32120200	彈簧華司	Spring Washer	2	104	B051403111	B051403111	彈簧下座組	Spring Seat Assy.	1
53	B040003031	B040004041	活門組	Valve Assy	6	105	BJ40301000	BJ40301000	調壓彈簧	Pressure Regulating Spring	1
54	B040303020	B040304020	活門帽	Valve Cap	6	106	B051303110	B051303110	彈簧上座	Spring Seat	1
55	BJ20305000	BJ20403000	活門彈簧	Valve Spring	6	107	BS14108019200	BS14108019200	圓頭螺絲	Screw	2
56	B040103020	B040104020	活門塞	Valve Plug	6	108	B050303000	B050303000	調壓彈簧套	Pressure Regulating Pipe	1
57	B040236090	B040204030	活門座	Valve Seat	6	109A	B053003001	B053003001	調壓螺絲組	Pressure Regulating Screw Assy.	1
58	B040436090	B040404000	活門皮	Valve Packing	6	109	B053003000	B053003000	調壓螺絲	Pressure Regulating Screw	1
70	B030203000	B030204000	出水室	Outlet Chamber	1	109-1	B053101000	B053101000	三角鐵片	Set Plate	1
	B030203050	B030204310	出水室	Outlet Chamber	1	109-2	BS31112102	BS31112102	平面華司	Washer	1
71	B031603110	N/A	球形閥	Ball Valve	1	120	B050003311	B050003311	自動洩壓總成	Unloading Valve Assy.	1
72	B030703000	B030704000	出水塞頭	Plug	1	121	B050203000	B050203000	洩壓汽缸套	Unloading Valve Cylinder	1
73	B031604110	B031604110	球形閥	Ball Valve	1 or 2	123	BG2025003000	BG2025003000	方形環	Square Ring	1
74	B250001031	B250001031	壓力錶	Pressure Gauge	1	124	BG1030003501	BG1030003501	O形環	O-Ring	2
75	B030403000	B030404000	空氣室	Air Chamber	1	125	BJ50301010	BJ50301010	洩壓輔助彈簧	Auxiliary Spring	1
76	BG1033003900	BG1041004900	O形環	O-Ring	1	126	B052203001	B052203001	柱塞活門組	Piston Valve Body Assy.	1
90	B050003011	B050003011	安全弁組	Safety Valve Assy.	1	127	B052203000	B052203000	柱塞活門體	Piston Valve Body	1
91	B050103000	B050103000	迴水座	Overflow Chamber	1	128	BS14108010300	BS14108010300	圓頭螺絲	Screw	1
92	BS11110025122	BS11110025122	六角螺絲附華司	Set Bolt, Washer	2	129	B052403000	B052403000	閥塞頭	Valve Plug	1
93	B031703000	B031703000	迴水桿底座	Overflow Rod Seat	1	130	BG1013001804	BG1013001804	O形環	O-Ring	1
94	BG2032003700	BG2032003700	方形環	Square Ring	1	131	B052503000	B052503000	閥塞座	Valve Plug Seat	1
94-1	BG2025003000	BG2025003000	方形環 25*30	Square Ring	1	132	BJ30301010	BJ30301010	球閥固定彈簧	Spring	1
95	B050603000	B050603000	調壓把手	Pressure Regulating Handle	1	133	B052303110	B052303110	彈簧底座	Spring Seat	1
96	BS12108013100	BS12108013100	大扁頭螺絲	Screw	2	134	B052603000	B052603000	C扣環	C-Clip	1
99A	B051003001	B051003001	壓力閥座組	Pressure Valve Seat Assy.	1	135	B051003010	B051003010	壓力閥座	Valve Seat	1
99	B051703000	B051703000	閥座套	Valve Sleeve	1	137	BG2032003700	BG2032003700	方形環	Square Ring	1
100	B051003000	B051003000	壓力閥座	Valve Seat	1	138	B050903000	B050903000	壓力閥	Pressure Valve	1
101A	B050903001	B050903001	壓力閥組	Pressure Valve Assy.	1	139	B050803011	B050803011	壓力閥桿組	Valve Rod Assy.	1
101	B050903000	B050903000	壓力閥	Pressure Valve	1	140	B051903000	B051903000	消音片	Damper Plate	1

No.	Code		品名	Description	PCS	No.	Code		品名	Description	PCS
	51	160					51	160			
141	BG1013501851	BG1013501851	O形環	O-Ring	2	#201 吸水管組僅含#201吸水管.#202吸水管蝶頭.#203A吸水管申目組					
142	B050503000	B050503000	迴水座	Overflow Chamber	460						
143	BS16108019300	BS16108019300	內六角螺絲	Hex Screw	4						
	BS32108300	BS32108300	彈簧華司	Spring Washer	4						
144	B071409000	B071409000	彈簧下座	Spring Seat	1						
145	BJ41101000	BJ41101000	調壓彈簧	Pressure Regulating Spring	1						
146	B071311000	B071311000	彈簧上座	Spring Seat	1						
147	B071709000	B071709000	調壓螺帽	Pressure Regulating Nut	1						
200A	N/A	B150104031	吸水管組含濾網	Suction Hose Assy., Filter	1						
200	B150903110	B150904020	過濾網	Filter	1						
	N/A	B150604010	過濾網申目	Filter Socket	1						
201	B150103001	B150104021	吸水管組	Suction Hose	1						
202	B150403110	B150404110	吸水管蝶頭	Suction Hose Wing Nut	1						
203A	B150503111	B150504111	吸水管申目組	Suction Hose Socket Assy.	1						
203	B150503110	B150504120	吸水管申目	Suction Hose Socket	1						
203-1	BG2028003703	BG2042005203	方形環	Square Ring	1						
204A	B150102001	B150102001	迴水管組	Overflow Hose Assy.	1						
205	B150402110	B150402110	迴水管蝶頭	Overflow Hose Wing Nut	1						
206A	B150502110	B150502110	迴水管申目組	Overflow Hose Socket Assy.	1						
206-1	BG2021002700	BG2021002700	方形環	Square Ring	1						
250	B160401000	B160401000	工具袋	Tool Kit	1						
251	B160703000	B160703000	調整環扳手	Adjusting-Ring Spanner	1						
252	B160603000	B160603000	十字起子	Cross-Screw Kit	1						
253	B160501000	B160501000	開口扳手12*14	Open Spanner	1						
254	B160503000	B160503000	開口扳手17*19	Open Spanner	1						
255	N/A	B160504000	開口扳手21*23	Open Spanner	1						
256	B150603110	B150604010	過濾網申目	Filter Socket	1						
257	B160703000	B160703000	調整環扳手	Adjusting-Ring Spanner	1						
258	N/A	B150404110	吸水螺帽	Suction Nut	1						
258	N/A	B031105000	壓力錶	Pressure Gauge	1						
260	B160803000	B160803000	螺絲包	Screw-Kit	1						2011V

51&160 EXPLODED VIEW

