


零件表PARTS LIST WH-1030 / WF-1030

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY
01	B010108000	曲軸箱	Crankcase	1	09	B010909020	曲軸油封	Crankshaft Oil Seal	2
01-1	B180608030	型式規格黏標	Model Label	1	10	B011008000	曲軸油封蓋	Crankshaft Oil Seal Cover	2
01-2	B180101000	流水號數黏標	Mfg. No. Label	1	10-1	BS12108010100	大扁頭螺絲	Set Bolt	8
01-3	B180107032	更換機油黏標	Oil Change Plate	1	12	B011602340	曲軸箱後蓋	Rear Cover	1
01-4	B180105000	柱塞潤滑油黏標	Notice Label	1	12A	B012201003	油鏡組	Oil Window Assy	1
01-5	B012901110	汽缸銷	Set Pin	2	12-1	B012201020	油鏡	Oil Window	1
02	B010208010	柱塞油封	Piston Oil Seal	3	12-2	BG1023402870	O形環	O-Ring	1
03	B010302000	腳座	Crankcase Stand	2	12-3	B011702000	後蓋迫緊	Rear Cover Packing	1
03-1	BS11112016122	六角螺絲附華司	Set Bolt & Washer	4	12-4	BS12108019101	大扁頭螺絲	Set Bolt	5
04A	B013008021	柱塞組	Piston Assy	3	13A	N/A	排油螺絲組	Drainage Screw Assy	1
04-1	B013108010	柱塞桿	Piston Rod	3	13	B011808000	排油螺絲	Drainage Screw	1
04-2	B013208001	柱塞套	Ceramic Piston	3	13-1	BG1010601770	O形環	O-Ring	1
04-3	B013408000	柱塞套固定螺帽	Set Nut	3	14	B011901111	加油蓋A	Oil Inlet Cover	1
04-4	B013308000	柱塞套固定螺絲	Double-End Screw	3	21	B020108010	汽缸	Cylinder	1
04-5	B013508000	柱塞套平墊圈	Gasket	3	21-1	BS11112025300	六角螺絲	Set Bolt	4
04-6	BG3015601900	背托環	Back-Up Ring	3	21-2	BS32112300	彈簧華司	Spring Washer	4
04-7	BG1014001850	O形環	O-Ring	3	21-3	BS11110025300	六角螺絲	Set Bolt	2
04-8	B013508010	柱塞套透氣墊圈	Gasket	3	21-4	BS32110300	彈簧華司	Spring Washer	2
05	B010502110	柱塞銷	Piston Pin	3	22	B020308050	U迫緊	U-Packing	3
06A	N/A	連桿組	Connecting Rod Assy	1	23	B020308040	U迫緊墊片	Gasket	3
06	B010609011	連桿	Connecting Rod	3	24	B020508020	調整環	Adjusting Ring	3
06-1	BS11208035500	六角螺絲	Set Bolt	6	24-1	BG1034603723	O形環	O-Ring	3
06-2	BS31208503	平面華司	Washer	6	24-2	B021008020	防水油封	Waterproof Oil Seal	3
06-3	B014309000	螺絲防鬆片	Lock Washer	3	24-3	B023908110	潤滑綿墊圈	Gasket	3
07	B010709010	軸承	Bearing	2	25	B011308020	潤滑綿	Felt Collar	3
08	B010809520	曲軸	Crankshaft	1	26	B023908000	潤滑綿墊圈	Gasket	3
08-1	B012101110	曲軸鍵	Crankshaft Key	1	27	BS4303500	彈簧式扣環	Ring	3

零件表PARTS LIST WH-1030 / WF-1030

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY
28	B011402110	防塵蓋	Dustproof Cap	1	62	BJ50901000	洩壓輔助彈簧	Auxiliary Spring	1
29	B011202010	柱塞中間皮	Waterproof Ring	3	63	B070609000	柱塞活門體	Piston Valve Body	1
30A	B040008001	進水活門總成	Valve Assy	3	63-1	BG1015002002	O形環	O-Ring	2
30-1	B040308010	進水活門帽	Valve Cage	3	63-2	BG3016202000	背托環	Back-Up Ring	3
30-2	BJ20202000	活門彈簧	Valve Spring	3	64	B070709000	止水閥塞	Valve Seat	1
30-3	B040108000	活門塞	Valve Plug	6	65	BJ30901000	球閥固定彈簧	Spring	1
30-4	B040208010	進水活門座	Valve Seat	3	66	B070809000	球閥固定套	Ball Valve Seat	1
30-5	BG1022002702	O形環	O-Ring	3	67A	B070409001	壓力閥座組	Valve Seat Assy	1
30-6	BG3022802680	背托環	Back-Up Ring	3	67	B070409000	壓力閥座	Valve Seat	1
31A	B040008011	出水活門總成	Valve Assy	3	67-1	BG3018302231	背托環	Back-Up Ring	1
30-3	B040108000	活門塞	Valve Plug	3	67-2	BG1017002202	O形環	O-Ring	1
31-1	B040308000	出水活門帽	Valve Cage	3	67-3	BG1020002502	O形環	O-Ring	1
31-2	BJ20801000	出水活門彈簧	Valve Spring	3	68	B070309000	陶瓷球閥	Ceramic Ball Valve	1
31-3	B040208000	出水活門座	Valve Seat	3	69	B070509000	壓力閥桿	Valve Rod	1
31-4	BG1022002702	O形環	O-Ring	3	70	B070909000	消音片	Damper Plate	1
40	B021308010	進水固定螺絲	Valve Bolt	3	71	BG1011001502	O形環	O-Ring	2
40-1	BG1025003203	O形環	O-Ring	3	72	B070209000	迴水座	Overflow Chamber	1
41	B021308000	出水固定螺絲	Valve Bolt	3	72-1	BS14108022100	圓頭螺絲	Screw	4
41-1	BG3025803190	背托環	Back-Up Ring	3		BS32108200	彈簧華司	Spring Washer	4
41-2	BG1025003203	O形環	O-Ring	3	73	B071810000	迴水接頭	Overflow Coupling	1
42	B021708000	進水接頭	Inlet Connector	1	74	B071409000	彈簧下座	Spring Seat	1
43	B071209000	出水接頭	Outlet Connector	1	75	BJ41101000	調壓彈簧	Pressure Regulating Spring	1
51	B031109000	壓力錶	Pressure Gauge	1	76	B071311000	彈簧上座	Spring Seat	1
52	B031209000	壓力錶接頭	Pressure Gauge Coupling	1	77	B071709000	調壓螺帽	Pressure Regulating Nut	1
60A	B070008001	自動洩壓總成	Unloading Valve	1	78	BS5000800	PT1/4塞頭	Plug	1
61	B070109000	洩壓汽缸套	Unloading Valve Cylinder	1	93	BK20201040	快速接頭 (選配)	Quick Connector(optional)	1
★	B070609001	柱塞活門組	Piston Valve Assy	1	★註：WF-1030不含圖號#63A柱塞活門組				



WH-1030
WF-1030