



PARTS LIST

HANDY BLOWER

HB2302

NOTE:

1. Use HUSQVARNA ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. HUSQVARNA ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

Fig.1 ENGINE GROUP	2
Fig.2 BLOWER GROUP	4

APPLICABLE SERIAL NUMBERS:

40600101 and up

April 2013

Fig.1 ENGINE GROUP




Fig.1 ENGINE GROUP

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	5580-12110	CYLINDER	1		53	3699-90332	SPARK PLUG	1	BRMR7A
2	848EKU12B4	GASKET, BASE	1		54	5500-73201	CORD COMP.	1	
3	1850-12130	BOLT	2	M5x22	55	848L0E90C2	LABEL	1	
4	5500-13163	INSULATOR	1		56	5516-81000	CARBURETOR ASSY	1	WYJ-110
5	5500-13121	GASKET, insulator	1		57	1850-81450	• BODY ASSY-PUMP	1	
6	5500-13131	GASKET, carb	1		58	3306-81380	• • SCREEN-INLET	1	
7	0263-90520	SCREW	2	M5x20	59	1850-81490	• BODY ASSY, air purge	1	
8	5516-15101	MUFFLER ASSY	1		60	1850-81520	• COVER	1	
10	1601-15120	• ARRESTER	1		61	1751-81510	• PUMP	1	
11	5516-15160	BOLT	2	M5x75	62	3310-81260	• DIAPHRAGM ASSY, met'g	1	
12	5516-15210	GASKET, muffler	1		63	1850-81470	• GASKET	1	
13	5500-15221	PLATE	1		64	1065-81420	• DIAPHRAGM ASSY, met'g	1	
14	0263-90416	SCREW	1	M4x16	65	1065-81410	• GASKET	1	
15	5881-21101	CRANKCASE COMP.	1		66	5516-81250	• JET	1	
16	5500-21141	GASKET	1		67	1751-81240	• O-RING	1	
17	06030-06001	BEARING	2		68	1751-81130	• RING	1	
18	4810-21210	SEAL	1		69	1881-81140	• SWIVEL	1	
19	1850-21220	SEAL	1		70	5516-81150	• VALVE ASSY	1	
20	04065-02812	SNAP RING	1		71	1752-81110	• SCREW	2	
21	01252-30530	BOLT	4	M5x30	72	5500-81120	• BRACKET	1	
22	5500-22110	GUARD	1		73	1751-81180	• NUT	1	
23	0263-90514	SCREW	1	M5x14	74	1918-81170	• SCREW	1	
24	5600-41111	PISTON	1		75	1881-81130	• RING	1	
25	1100-41210	RING	2		76	1850-81530	• SCREW	4	
26	1101-41310	PIN	1		77	5500-81160	• WASHER	1	
27	1260-41320	RING	2		78	0263-90560	SCREW	2	
28	5500-41410	BEARING	1		79	5516-83101	CABLE	1	
29	1101-41340	WASHER	2		80	5516-82001	CLEANER ASSY	1	
30	5500-42001	CRANKSHAFT COMP.	1		81	1918-82110	• COVER	1	
31	5516-43230	EXTENTION	1		82	1918-82120	• FILTER	2	
32	1000-43240	KEY	1		83	1918-82180	• SCREEN	1	
33	5501-71110	ROTOR	1		84	1918-82130	• HOUSING	1	
34	5501-71201	COIL ASSY	1		85	1918-82140	• PLATE	1	
35	5500-71220	• CORD	1		86	5516-82150	• CHOKE VALVE	1	
36	2616-71320	• CAP	1		87	1918-82160	• WASHER	1	
37	5500-72110	CAP, plug	1		88	1918-82170	• SLEEVE	2	
38	1900-72120	SPRING	1		89	5516-82120	• SILENCER	1	
39	5500-72130	GROMMET	1		90	5516-85004	TANK ASSY	1	
40	1260-71261	SPACER	2		91	5607-85201	• CAP ASSY	1	
41	3310-72150	BOLT	2	M4x25	92	5601-85300	• • HOLDER ASSY	1	
42	5500-75100	RECOIL ASSY	1		93	5500-85220	• • PACKING	1	
43	1850-75120	• REEL	1		94	5601-85260	• • FILTER	1	
44	1850-75130	• SPRING	1		95	4820-85260	• • STOPPER	1	
45	1850-75151	• SCREW	1		96	5911-85300	• PIPE COMP	1	
46	1850-75160	• ROPE	1		97	5500-85400	• FILTER	1	
47	1140-75320	• KNOB	1		98	1260-85460	• CLIP	1	
48	5500-75170	• PLATE	1		99	5516-85510	SCREW	3	M5x20
49	1850-75201	PULLEY ASSY	1		100	5516-85531	COLLAR	1	
50	1850-75221	• RATCHET	1		101	1950-86120	CLIP	1	
51	1850-75230	• SPRING	1		102	4500-81910	COVER	1	
52	0263-90416	SCREW	4	M4x16					

Fig.2 BLOWER GROUP




Fig.2 BLOWER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'ty /UNIT	NOTE
1	848L0F55A2	VOLUTE CASE	1						
2	T4022-11301	VOLUTE COVER ASSY	1						
3	1600-33130	• SCREW	3						
4	6811-11250	SCREW	12						
5	T4033-31310	GURD NET	1						
6	0263-30425	SCREW	1						
9	T4033-31350	SPRING	1						
10	T4033-31360	SHAFT	1						
11	T4033-32120	WASHER	1						
12	6811-11170	SCREW	1						
13	6811-11150	LEVER	1						
14	848L0L7200	SWITCH	1						
15	6811-11210	ENGINE COVER	1						
16	1850-32160	SCREW	1						
17	0263-90535	SCREW	4						
18	6811-12110	FAN	1						
19	1650-43230	NUT	1						
20	6811-12220	WASHER	2						
21	848L0E90S3	LABEL, CAUTION	1						
22	T2990-21060	LABEL (106dB)	1						
23	576 04 55-01	PIPE	1	CT2-18					
24	848L0L65E0	PIPE, END	1	CT2-19					
25	3073-91111	WRENCH	1						
27	3073-91111	WRENCH	1						
28	848L0A65G0	HANDLE	1						
29	8488553000	SCREW	2						
30	2756-51521	CLAMP	1						
31	848C1B90G0	LABEL	1						
OPTION									
41	848L740001	FLAT NOZZLE SET	1						
42	6811-51211	• PIPE	1						
43	6811-51230	• FLAT NOZZLE	1						
44	DB00004	VACUUM KIT	1	ACC					
45	848L736511	• PIPE COMP.	1						
46	T4027-52120	• DECAL	1						
47	T4027-52410	• EXTENSION	1						
48	T4027-52510	• ELBOW	1						
49	8488K40061	• CLAMP	1						
50	T4027-52710	• BAG, DUST	1						
51	0260-30425	• SCREW	1						
52	848L7365N0	• SPACER	1						