



PARTS LIST

BRUSHCUTTERS

EX2600-PH

NOTE :

1. Use HUSQVARNA ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. HUSQVARNA ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

APPLICABLE SERIAL NUMBERS:

20143600101 and up

July 2014


Fig.1 CUTTER GROUP

Fig. 1 EX2600-PH

CUTTER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	848J8P5820	PIPE COMP.	1	ø24x750
2	T3075-12210	SHAFT	1	786x7
3	6036-12250	SPACER	1	
4	580 88 61-01	JOINT, PIPE ASS'Y	1	
5	T3087-12600	• STOPPER COMP.	1	
6	580 88 60-01	• JOINT	1	
7	6036-12420	• KNOBBOLT	1	
8	01643-30823	• WASHER	1	
9	01252-30510	• BOLT	1	M5x10
10	3540-13260	• BOLT	1	
11	574 39 03-02	GRIP ASSY	1	
12	576 47 52-02	• GRIP, HALF SET	1	
13	8488RC0600	• LEVER, THROTTLE	1	
14	8488RJ0600	• SPRING, THROTTLE	1	
15	578 77 80-01	• LEVER, SAFETY	1	
16	848JL233F3	• SPRING	1	
17	8488RE0601	• LEVER, JOINT	1	
18	T4506-52110	• SWITCH	1	
19	8488241600	• SCREW	4	
20	8488P40550	• CABLE COMP.	1	
21	8488M10820	• CORD COMP.	2	
22	T3003-14510	• TUBE	1	
23	8488RH0421	• BAND	2	
24	4820-13180	• BOLT	2	
25	8488605000	• NUT	2	
26	T3300-17202	HANGER COMP.	1	
27	8488052000	• SCREW	1	
28	585 07 49-04	PLATE-NAME	1	
29	T3110-14000	HANDLE ASSY	4	
30	T3110-14110	• HANDLE	1	
31	0263-90530	• SCREW	1	
32	848J823610	STRAP ASSY	1	
33	587 19 40-01	TOOL-SET	1	
34	8488U10080	• WRENCH	1	
35	09007-00425	• WRENCH	1	
36	09007-00528	• WRENCH	1	
37	3540-91110	• BAR	1	
38	1030-91340	• DRIVER	1	
39	8488U10040	• SOCKET	1	
40	T3002-91190	GOGGLE	1	


Fig.2 ENGINE GROUP (1)

Fig. 2 EX2600-PH

ENGINE GROUP (1)

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	T1800-12111	CYLINDER	1	M5x22 BPMR7A
2	515 40 88-01	GASKET, BASE	1	
3	1850-12130	BOLT	2	
4	3699-90332	SPARK PLUG (NGK)	1	
5	5881-21102	CRANKCASE COMP.	1	
6	2629-21130	• PIN	3	
7	5500-21141	GASKET	1	
8	T1802-21240	BEARING	2	
9	2169-21210	SEAL	1	
10	1850-21220	SEAL	1	
11	04065-02812	SNAP RING	1	ø 28
12	01252-30530	BOLT	4	M5x30
13	5500-42001	CRANKSHAFT COMP.	1	
14	5910-41110	PISTON	1	ø 34
15	8488C34200	RING	2	ø 34
16	1600-41310	PIN	1	
17	1260-41320	RING	2	
18	5500-41410	BEARING	1	
19	1101-41340	WASHER	2	
20	T1700-15110	MUFFLER	1	
21	01252-30550	BOLT	2	M5x50
22	T1600-15210	GASKET	1	M4x16
23	5500-15221	PLATE	1	
24	0263-90416	SCREW	1	
25	T1700-71110	ROTOR	1	
26	T1700-71201	COIL ASSY	1	
27	5500-72110	• CAP	1	
28	T1700-71220	• CORD	1	
29	2616-71320	• CAP	1	
30	5500-72130	• GROMMET	1	
31	5500-72120	• SPRING	1	M4x20
32	3310-72150	BOLT	2	
33	T1700-71260	SPACER	2	
34	T1700-73200	CORD COMP.	1	
35	1650-43230	NUT	1	M8
36	1000-43240	KEY	1	


Fig.3 ENGINE GROUP (2)

Fig. 3 EX2600-PH

ENGINE GROUP (2)

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	T1700-13160	INSULATOR	1	
2	5500-13122	GASKET, INSULATOR	1	
3	5500-13131	GASKET, CAB	1	
4	0263-90520	SCREW	2	M5x20
5	848EFG8101	CARBURETOR ASSY	1	WYJ-290B
6	T1825-82510	PLATE	1	
7	T1825-82521	GASKET	1	
8	T1700-82100	BODY ASSY	1	
9	1970-82190	• SLEEVE	2	
10	T1700-82130	• PLATE, CHOKE	1	
11	T1700-82140	• LEVER, CHOKE	1	
12	2630-33610	• SCREW	1	
13	5500-82171	ELEMENT	1	
14	T1701-82200	COVER, ASSY	1	
15	5500-82221	• KNOB	1	
16	0263-90560	SCREW	2	M5x60
17	T1800-85001	TANK ASSY	1	
18	5607-85201	• CAP ASSY	1	
19	5601-85300	• • HOLDER ASSY	1	
20	5500-85220	• • PACKING	1	
21	5601-85260	• • FILTER	1	
22	4820-85260	• • STOPPER	1	
23	5500-85300	• PIPE COMP	1	
24	5500-85400	• FILTER ASSY	1	
25	1260-85460	• CLIP	1	
26	5910-85510	SCREW	1	M5x16
27	5500-85510	SCREW	2	M5x16
28	4500-81910	COVER	1	
29	1950-86120	CLIP	1	


Fig.4 ENGINE GROUP (3)

Fig. 4 EX2600-PH

ENGINE GROUP (3)

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	5500-22110	GUARD	1	
2	0263-90514	SCREW	1	M5x14
3	T1702-31101	HOUSING ASSY	1	
4	T1701-31151	• BEARING	1	
5	848F3051A1	• DRUM	1	
6	04064-01210	• RING	1	ø 12
7	04065-02812	• RING	1	ø 28
8	T1700-31212	BRACKET (A)	1	
9	T1700-31221	BRACKET (B)	1	
10	T1700-31232	CUSHION	1	
11	01252-80522	BOLT	2	M5x22
12	01252-80510	BOLT	1	M5x10
13	0263-90520	SCREW	2	M5x20
14	T1600-72210	CLAMP	1	
15	T1700-32112	COVER, ENGINE	1	
16	T1700-32162	SCREW	1	M5x16
17	0263-90514	SCREW	1	M5x14
18	848EA05110	SHOE COMP.	1	
19	T1700-51220	• SPRING	1	
20	1140-51250	SCREW	2	
21	1140-51230	WASHER	2	
22	T1600-51240	WASHER	2	
23	T1700-75100	RECOIL ASSY	1	
24	5500-75110	• CASE COMP.	1	
25	1850-75120	• REEL	1	
26	1850-75130	• SPRING	1	
27	1850-75151	• SCREW	1	
28	T1600-75160	• ROPE	1	
29	T1600-75310	• KNOB	1	
30	T1600-75321	• COLLER	1	
31	T1600-75330	• SPRING	1	
32	T1600-75210	• WASHER	1	
33	1850-75201	PULLY, ASSY	1	
34	1850-75221	• RATCHET	1	
35	1850-75230	• SPRING	1	
36	T1700-32162	SCREW	4	M5x16
37	T1807-75411	LABEL, RECOIL	1	
38	T1600-31131	LABEL	1	
39	848EGY85Z0	GUARD	1	
40	3350-21320	BOLT	2	M5x30


Fig.5 CARBURETOR

Fig. 5 EX2600-PH

CARBURETOR

Key#	PART NUMBER	DESCRIPTION	Q'TY	REMARKS
1	848EFG8101	CARBURETOR ASSY	1	WYJ-290B
2	1794-81450	• BODY ASSY	1	
3	3306-81380	• • SCREEN	1	
4	3356-81310	• • VALVE, inlet	1	
5	1794-81270	• • SPRING	1	
6	1850-81220	• • SCREW	1	
7	3310-81250	• • PIN	1	
8	3310-81230	• • LEVER	1	
9	1850-81490	• BODY	1	
10	1850-81520	• COVER, pump	1	
11	1751-81510	• PUMP, primer	1	
12	848HE081K0	• DIAPHRAGM	1	
13	1850-81470	• GASKET	1	
14	1065-81420	• DIAPHRAGM, pump	1	
15	4810-81410	• GASKET	1	
16	T1513-81250	• JET	1	#39
17	1751-81240	• O-RING	1	
18	1751-81130	• RING	1	
19	1881-81140	• SWIVEL	1	
20	5500-81160	• WASHER	1	
21	T1700-81150	• VALVE ASSY	1	
22	1752-81110	• SCREW	2	
23	5500-81120	• BRACKET	1	
24	1751-81180	• NUT, adjuster	1	
25	1918-81170	• SCREW, adjuster	1	
26	1881-81130	• RING	1	
27	1850-81530	• SCREW	4	