

PORTABLE GAS DRILL


EDG2300

NOTE :

1. Use Husqvarna Zenoah genuine parts as specified in the parts list for repair and/or replacement.
2. Husqvarna Zenoah does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list may change due to improvement.
5. The parts for the machine shall be supplied seven (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of seven (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of seven (10) years.]

February 2013

APPLICABLE SERIAL NUMBERS : 901112 and up




EDG2300

Fig.1 DRIVE UNIT and TOOLS (S/N 901112 and up)

Key#	Part Number	Description	Q'ty	Key#	Part Number	Description	Q'ty
1	3871-21100	Right handle comp.	1				
2	3871-21120	• Grip	1				
3	3871-21320	Stay	1				
4	3545-14240	Bolt	1				
5	01641-21423	Washer	1				
6	3524-14400	Lever, Throttle	1				
7	0280-10504	Nut	1				
8	01601-20513	Washer	1				
9	0263-30516	Screw	2				
10	0280-10504	Nut	2				
11	3872-21510	Bracket, Right	1				
12	3871-21200	Left handle comp.	1				
13	3541-14221	• Grip	1				
14	3872-21520	Bracket, Left	1				
15	0225-30616	Bolt	4				
16	0225-10616	Bolt	4				
17	3890-11102	Case Comp., Rear half	1				
18	3890-11140	• Dowel pin	2				
19	3890-11201	Case comp., Front half	1				
20	T1802-21240	Bearing	1				
21	06031-06001	Bearing (Single shield)	1				
22	06030-06202	Bearing	1				
23	06034-06202	Bearing (Double shield)	1				
24	3127-13230	Spacer	1				
25	04065-03515-50	Ring	1				
26	3890-12110	Clutch drum	1				
27	04064-01210	Ring	1				
28	3872-13101	Gear comp., Drive	1				
		• Gear, Idler	1				
		• Key	1				
30	04010-00310	Key	1				
31	3872-13140	Gear, Driven	1				
32	3890-13140	Shaft, PTO	1				
33	0224-00610	Bolt	1				
34	01641-20608	Washer	1				
35	3310-12281	Screw	4				
36	3872-13150	Nut	1				
37	3872-91000	Tool set	1				
38	3541-91110	• Bag	1				
39	1030-91340	• Screwdriver	1				
40	1110-91320	• Scket (Hex. 19mm)	1				
41	3540-91120	• Spanner (8mm x 10mm)	1				
42	3871-91350	• Spanner (17mm x 13mm)	1				

Parts List : EDG2300

Fig.2 ENGINE UNIT (S/N 901112 and up)



EDG2300

Fig.2 ENGINE UNIT (S/N 901112 and up)

Key#	Part Number	Description	Q'ty	Key#	Part Number	Description	Q'ty
1	5602-12110	CYLINDER	1	64	_____	••• SCREEN	—
2	5500-12213	GASKET, base	1	65	_____	••• VALVE	—
3	1850-12130	BOLT M5x12	2	66	_____	••• SPRING	—
4	5500-13163	INSULATOR	1	67	_____	••• SCREW	—
5	5500-13122	GASKET, INSULATOR	1	68	_____	••• PIN	—
6	5500-13131	GASKET, CARB	1	69	_____	••• LEVER	—
7	0263-90520	SCREW M5x20	2	70	5602-06020	•• GASKET KIT	1
8	5602-15100	MUFFLER ASSY	1	71	_____	••• DIAPHRAGM ASSY	—
10	1601-15120	• ARRESTER	1	72	_____	••• GASKET	—
11	01252-30550	BOLT M5x55	2	73	_____	••• DIAPHRAGM	—
12	5500-15210	GASKET, MUFFLER	1	74	_____	••• GASKET	—
13	5600-15220	PLATE	1	75	1850-81490	• BODY	1
14	0263-90416	SCREW M4x16	1	76	1850-81520	• COVER	1
15	5600-21100	CRANKCASE COMP.	1	77	1751-81510	• PUMP	1
16	5500-21141	GASKET	1	78	5500-81251	• JET	1
17	T1802-21240	BEARING	2	79	1751-81240	• O-RING	1
18	2169-21210	SEAL	1	80	1751-81130	• RING	1
19	1850-21220	SEAL	1	81	5500-81160	• WASHER	1
20	04065-02812	RING	1	82	1881-81140	• SWIVEL	1
21	01252-30530	BOLT M5x30	4	84	1752-81110	• SCREW	2
22	5600-41111	PISTON	1	85	5500-81120	• BRACKET	1
23	848-8C3-2300	RING	2	86	0282-10604	• NUT	1
24	1101-41310	PIN	1	87	T1600-13170	• SCREW	1
25	1260-41320	RING	2	88	1881-81130	• RING	1
26	5500-41410	BEARING	1	89	1850-81530	• SCREW	4
27	1101-41340	WASHER	2	90	0263-90560	SCREW M5x60	2
28	5600-42001	CRANKSHAFT COMP.	1	91	1950-86120	CLIP	1
29	1650-43230	NUT	1	92	5500-82102	BODY ASSY	1
30	1000-43240	KEY	1	93	1970-82190	• SLEEVE	2
31	1140-51111	SHOE	2	94	5500-82131	• PLATE	1
32	1140-51250	SCREW	2	95	5500-82140	• LEVER	1
33	1970-51221	SPRING	1	96	2630-33610	• SCREW	1
34	1140-51230	WASHER	2	97	5500-82171	ELEMENT	1
35	1970-51241	WASHER	2	98	5600-82203	COVER ASSY	1
36	1140-21162	CASE	1	99	5500-82221	• KNOB	1
37	0263-90516	SCREW M5x16	4	100	5600-31110	COVER	1
38	5600-52150	PLATE	1	101	0263-90520	SCREW M5x20	4
39	1650-43230	NUT	1	102	5600-32101	COVER	1
40	5601-71110	ROTOR	1	103	1850-32160	SCREW M4x12	1
41	5600-71200	COIL ASSY	1	104	1900-31410	SCREW	2
42	5600-71220	• CORD, HIGH	1	105	3699-90332	SPARKPLUG NGK BPMR7A	1
43	2616-71320	• CAP	1	106	5600-73210	SWITCH ASSY	1
44	5500-72110	CAP	1	107	5580-83100	CABLE COMP.	1
45	1900-72120	SPRING	1	108	5607-85002	TANK ASSY	1
46	1260-71261	SPACER	2	109	5607-85201	• CAP ASSY	1
47	3310-72150	BOLT M4x25	2	110	5500-85220	•• PACKING	1
48	5500-72130	GROMET	1	111	5601-85300	•• HOLDER ASSY	1
49	5990-75102	RECOIL ASSY	1	112	5601-85260	•• FILTER	1
51	5990-75120	• SPRING	1	113	4820-85260	•• STOPPER	1
52	5990-75131	• REEL	1	114	5500-85300	• PIPE COMP.	1
53	5990-75141	• RATCHET	1	115	5500-85400	• FILTER ASSY	1
54	5990-75151	• SPRING	1	116	1260-85460	• CLIP	1
55	5990-75270	• SCREW	1	117	5500-85510	SCREW M5x16	1
56	5990-75160	• RETAINER	1	118	5635-87112	PLATE	1
57	5990-75170	• WASHER	1	119	0263-90520	SCREW M5x20	2
58	1861-75180	• ROPE	1	120	1757-87200	JOINT	1
59	1490-75181	• KNOB	1	121	1757-87220	• BAND	1
60	0263-90412	SCREW M4x16	4	122	0280-10504	NUT M5	1
61	5501-81000	CARBURETOR ASSY	1	123	01601-20513	WASHER	1
62	5602-06030	• REBUILT KIT	1	124	5636-91122	LABEL, RECOIL	1
63	1850-81450	•• BODY ASSY	1				